

# FAT BIKE

## Best Practices

- 1. Wide tires only. Minimum width 3.7"**
- 2. Tire pressure no higher than 8 PSI**
- 3. Enough floatation that when traveling over the snow you don't leave a rut deeper than 1"**
- 4. Sufficient traction that you are able to control your bike safely in a straight line.**
- 5. Do not disturb the wildlife.**
- 6. Understand changing conditions.**
- 7. Be prepared if you have to stay out longer than planned.**
- 8. Let people know where you are going if riding alone.**
- 9. Share the trail with snowshoers.**

**For information about this riding area  
please go to [madcitydirt.com](http://madcitydirt.com)**

**JOIN \* DONATE \* VOLUNTEER**

